

Information- and Data Sheet according to the Requirements of the Blue Angel Environmental Label for Office Equipment with Printing Function (DE-UZ 219)

Kyocera ECOSYS P6235cdn

(Print speed maximal 35 pages/minute both in monochrome and colour)

General Information

The ECOSYS P6235cdn has been awarded the Blue Angel ecolabel. The device is intended for professional use. The following notes refer to the award criteria:

- Use only Kyocera toner kits specifically designed for this printer, as they have been tested and found to meet the requirements of the Blue Angel ecolabel.
- Please only carry out the cleaning steps for the device described in the user manual. Only trained persons may carry out maintenance and disposal activities as well as complete cleaning of the system.
- Do not force open the toner containers. If toner dust escapes because of improper handling, avoid inhalation of the dust and contact with the skin. If skin contact should occur, wash with soap and cold water. Keep the toner container out of reach of children.
- The device contains 1-5% of recycled plastic (post-consumer recycled plastic).
- The black toner included in the delivery state is sufficient for 6,000 pages. Cyan, magenta and yellow are each sufficient for 5,000 pages (data according to ISO/IEC 19798).
- Once a Kyocera toner is empty, we offer a number of ways to return it to our recycling partner, depending on your location. For further information, please visit <https://www.kyoceradocumentsolutions.eu/en/support/return-your-toners/toner-take-back-service.html>.
- The printer is suitable for using recycled paper according to EN 12281.
- To save paper and thus conserve resources, the printer is equipped with a duplex unit for two-sided printing.
- In addition, the functions "Skip blank pages" and multi-page printing (print multiple pages on one sheet) are also available.
- The dealer will replace the maintenance kits, including the photoconductor drums after 200,000 pages (A4) at a fee. In the course of maintenance, installed filters are inspected and replaced if necessary.
- New electronic units emit volatile compounds into the room air during the first few days. Therefore, please ensure sufficient air exchange in the installation room.
- Kyocera or its representative provides a standard one-year warranty as a basis. For all detailed country and product specific warranty conditions and service offerings please refer to the service and support section of your local Kyocera homepage first.
- To ensure repair reliability, spare parts and consumables are available for at least 5 years after production has been discontinued.
- The return of the printing system is regulated. Business customers should contact their Kyocera dealer or Kyocera Document Solutions directly.

- The Panasonic CR2032 battery contained in the print system is free of cadmium, lead and mercury. Removal is not required as it does not need to be replaced within the life of the system.

1. Information on Noise Emissions of the ECOSYS P6235cdn

The declared sound power level $L_{WA,d}$ according to the regulations of DE-UZ 219 is 67.7 dB(A) for the monochrome printing and 68.1 dB(A) for the colour printing process.

2. Information on Energy Data of the ECOSYS P6235cdn

The electric power consumption of a device depends on both its features and also on the way these features are utilised by the user.


The device ECOSYS P6235cdn has been designed and pre-set so that you can save electricity costs. It switches to "Ready-mode" after the last print.

From this mode, it is able to print again immediately if required. If this is not required, the device will switch to an electric power saving mode after a certain period of time, which is called the delay time. It consumes less power (watts) in this mode. The device will take longer to print again from an electric power saving mode than from "Ready-mode". This delay is called the recovery time. The device has been designed in such a way that switching it on and off up to twice a day into "Off-mode" will not damage the device.

You can find the power consumption values for the individual modes, as well as the delay and recovery times, in the table below. The values stated in the table are pre-set when the device is delivered. The device complies with the requirements of the Blue Angel with these values.

Overview of the Operating Modes of the ECOSYS P6235cdn

Print speed in DIN A4 format (determined according to: ISO/IEC 24734): 35 pages/minute

Symbol on the switch/button	Operation-mode	Power consumption ¹ [watts]	Delay time ² [minutes]	Recovery time ³ [seconds]
	Highest possible power consumption: at switch on	1297	-	-
	Printing (continuous operation at 35 pages/minute) monochrome	510	-	-
	Ready-mode	74	0	-
	Sleep-mode	0.6	1 (1...120)	10
	Off-mode	0.2	Switch activation	

1 Averaged values, measured without accessories

2 The delay time is the time that elapses after the end of the printing process until the device switches over to the respective operating mode. The figures in brackets indicate the range within which you can change the delay time.

3 The recovery time is the time which the device needs to return to "Ready-mode" for printing.

3. Energy Consumption of the ECOSYS P6235cdn

For the standard use cycle according to the ENERGY STAR 3.0 standard, the following assumptions are made for a device like the ECOSYS P6235cdn: 32 print jobs per working day, each with 19 pages, single-sided using monochrome printing (608 pages/day).

The energy consumption for a week (7-day week with 5 working days of 8 hours each) in the standard use cycle according to ENERGY STAR 3.0, determined using printing test pattern A according to ISO 10561:1999, is 0.49 kWh/week.

This value was measured with the settings (delivery state) stated above.

You can change the delay times for the electric power saving modes in some cases. If you shorten a delay time, the device will switch to an electric power saving mode faster and you will save electricity costs. If you nevertheless want to extend a delay time, please bear the following in mind:

The device will switch to an electric power saving mode later or not at all. The device will thus remain in a mode with higher power consumption for a longer period of time and will consume more electric power as a result. In addition, it is possible that the device will no longer comply with the maximum value for electricity consumption specified by the Blue Angel. We recommend that you do not extend the delay times.

The power consumption can only be completely stopped by pulling the mains plug.

User information on the Blue Angel as well as the environmental data sheet can be found in the download centre under the respective printer or multifunctional device:

<https://www.kyoceradocumentsolutions.eu/en/support/downloads.html>.

Further information on DE-UZ 219 can be found at <https://www.blauer-engel.de/en>.

KYOCERA Document Solutions Deutschland GmbH
Otto-Hahn-Straße 12 – 40670 Meerbusch
Infoline +49 (0)800 1871877 – Telefax +49 (0)2159 918-106
www.kyoceradocumentsolutions.de

