

Toner module (Designation of the applicant)	Toner module (Designation of the OEM-manufacturer)	To be used in following Office Equipment with Printing Function
NT-CH201 B BK/Y/M/C	HP CF400X/CF402X/CF403X/CF401X	HP COLOR LASERJET M252/252N/252DN/252DW/M277N/M277DW
NT-PH201 B BK/Y/M/C	HP CF400A/CF402A/CF403A/CF401A	HP COLOR LASERJET M252/252N/252DN/252DW/M277N/M277DW
NT-PH202 B BK/Y/M/C	HP CF500X/CF502X/CF503X/CF501X	HP COLOR LASERJET M254DW/M254NW/M281FDN/M281FDW/M280NW
NT-PH210 B BK/PH211 B C/PH212 B Y/ PH213 B M	HP CF210A/CRG131BK/CRG731BK/CRG331BK; CF211A/CRG131C/CRG731C/CRG331C; CF212A/CRG131Y/CRG731Y/CRG331Y; CF213A/CRG131M/CRG731M/CRG331M	HP LASERJET PRO 200 COLOR PRINTER M251N/NW/MFP M276N/NW;CANON I-SENSYS LBP-7100CN/7110CW;SATERA LBP7100C
NT-PH203 B BK/Y/M/C	HP CF540A/CF541A/CF543A/CF542A	HP COLOR LASERJET M254DW/M254NW/M281FDN/M281FDW/M280NW
NT-PH205 B BK/Y/M/C	HP CF530A/CF531A/CF533A/CF532A	HP COLOR LASERJET M154A/M154NW,M180/180N/M181/M181FW
NT-PH320 B BK/PH321 B C/PH322 B Y/ PH323 B M	HP CE320A/CE321A/CE322A/CE323A	HP LASERJET PRO CP1525N/CP1525NW/CM1415FN MFP/CM1415FNW MFP
NT-PH305 B BK/Y/M/C	HP CE410A/CE412A/CE413A/CE411A	HP LASERJET PRO 300 COLOR M351A/MFP M375NW;LASERJET PRO 400 COLOR PRINTER M451NW/M451DN/M451DW/MFP M475DN/MFP M475DW
NT-PH410 B BK/PH411 B C/PH412 B Y/ PH413 B M	HP CF410A/CF411A/CF412A/CF413A	HP COLOR LASERJET M452DW/M452DN/M452NW/M477FDW/477DN/M477NW
NT-PC045 B BK/Y/M/C	Canon Cartridge 045 Black/ Yellow/Magenta/Cyan	CANON IMAGECLASS MF634CDW/MF632CDW/LBP612CDW;CANON I-SENSYS LBP611CN/LBP613CDW;CANON I-SENSYS MF631CN/MF633CDW/MF635CX
NT-PH540 B BK/PH541 B C/PH542 B Y/ PH543 B M	HP CB540A/CRG116BK/CRG716BK/CRG316BK; CB541A/CRG116C/CRG716C/CRG316C; CB542A/CRG116Y/CRG716Y/CRG316Y; CB543A/CRG116M/CRG716M/CRG316M	HP COLOR LASERJET CP1215/CP1217/CP1510/CP1514/CP1515N/CP1518NI/CM1312 MFP/CM1312N MFP/CM1312NFI MFP;LASERJET PRO CP1525N/CP1525NW/CM1415FN MFP/CM1415FNW MFP;LASERJET PRO 200 COLOR PRINTER M251N/NW/MFP M276N/NW;CANON I-SENSYS LBP5050/LBP5050N/MF8030CN/MF8040CN/MF8050CN/MF8080 CW;IMAGECLASS MF8050CN/MF8080CW;SATERA MF8050CN/MF8030CN(JP)
NT-PH530 B BK/PH531 B C/PH532 B Y/ PH533 B M	HP CC530A/CRG118BK/CRG718BK/CRG318BK; CC531A/CRG118C/CRG718C/CRG318C; CC532A/CRG118Y/CRG718Y/CRG318Y; CC533A/CRG118M/CRG718M/CRG318M	HP LASERJET PRO 300 COLOR M351A/MFP M375NW;LASERJET PRO 400 COLOR PRINTER M451NW/M451DN/M451DW/MFP M475DN/MFP M475DW;COLOR LASERJET CP2020/CP2025/CP2025N/CP2025DN/CM2320 MFP/CM2320N MFP/CM2320NF MFP/CM2320FXI MFP;HP COLOR LASERJET PRO M476DN MFP/M476DW MFP/M476NW MFP;CANON IMAGECLASS MF8350CDN/MF8380CDW;I-SENSYS LBP- 7200CDN/7210CDN/7660CDN/7680CX;I-SENSYS MF- 8330CDN/8340CDN/8350CDN/8360CDN/8380CDW;SATERA MF8350CDN/MF8330CDN(JP)
NT-PC318 B BK/Y/M/C	Canon CRG118BK/CRG718BK/CRG318BK; CRG118Y/CRG718Y/CRG318Y; CRG118M/CRG718M/CRG318M; CRG118C/CRG718C/CRG318C	CANON LBP-7200C/CN/LBP-7600C
NT-PC316 B BK/Y/M/C	Canon CRG116BK/CRG716BK/CRG316BK; CRG116Y/CRG716Y/CRG316Y; CRG116M/CRG716M/CRG316M; CRG116C/CRG716C/CRG316C	CANON LBP 5050
NT-PH380 B BK/PH381 B C/PH382 B Y/PH383 B M	HP CF380A/CF381A/CF382A/CF383A	HP COLOR LASERJET PRO M476DN MFP/M476DW MFP
NT-PC331 B BK/Y/M/C	Canon CRG-331BK/Y/M/C	CANON LBP-7100C/7110C