

Blue Angel Environmental Information and Data Sheet Model: IM C300

EDP: 418559

Issued: 01 January 2025

1 General Specification						
Primary functions of the base unit						
Model: IM C300		□ Copy	□ Print	☐ Fax	⊠ Scan	
Tachnalagu		☐ Monochrom	ne	⊠ Colour		
Technology		⊠ Electrophotographic		☐ Inkjet Tech	☐ Inkjet Technology	
Print Speed Simplex, DIN-A4 pages/min, according to ISO/IEC 24734		Monochrome:	30	Colour: 30		
Copying Speed Simplex, DIN-A4 pages/min, according to ISO/IEC 24735		Monochrome:	30	Colour: 30		
The system is designed for use	The system is designed for use in the professional/commercial sector.					
2 Technical Safety (Declaration	on of Conformity	/				
The system complies with the fo	llowing EU regu	lations as far a	s they are appl	icable and bears	s the CE mark	
 Radio Equipment Directive 2014/53/EU RoHS Directive 2011/65/EU ErP Directive 2009/125/EC 						
3 Environmental Labels						
www.blauer-engel.de/UZ219						
4 Use and labelling of materials						
The device is suitable for processing recycled paper that complies with EN 12281:2002 We recommend using the machine in duplex mode (double-sided copy/print). The model is equipped with a duplex and N-up function: ☐ Optional						
Toner/ Ink		☐ Ink				
Ames-Test	Negative (refer to Safety Data Sheet)					
Photo Conductor Unit	Organic Photo Conductor (OPC)					
Batteries	Mangandioxide	Lithium free of l	ead, cadmium a	nd mercury		
Flame Retardents	No halogenated flame retardants are used in housing parts and other plastic parts over 25 g, especially not: Polybrominated Biphenyles (PBB), Polybrominated Biphenylether (PBDE) and Tetrahrombischenel A (TBBDA)					

System: IM C300 Ausgabe: 01 January 2025

Seite 2 von 4

RICOH imagine. change.

Marking of Plastic Parts	All plastic parts >25g are marked in accordance with ISO 11469:2000 and ISO 1043.			
Proportion by weight of recycled plastic relative to total plastic (Post-consumer) Legal requirements for	□ 0 − 1 % □ 10 − 15 % □ 15 − 20 % □ 20 − 25 % The device fully complies with WEEE requirements.			
recycling (WEEE) 5 Yield of consumables	The device rany complies with WEEE	Toquilomon		
Consumable	Description	EDP	Yield (A4)	Test Procedure
	Print Cartridge Black IM C300	842382	19,300	
Tanan Cartridua	Print Cartridge Black IM C300 Print Cartridge Yellow IM C300	842382 842383	19,300 10,300	100/150 40700
Toner Cartridges			,	ISO/IEC 19798
Toner Cartridges	Print Cartridge Yellow IM C300	842383	10,300	ISO/IEC 19798

Note on the ranges given here: The actual yield depends on the image size and brightness, the number of pages to be printed at one time, the type and size of paper used, the contents of the printed images, and environmental conditions such as temperature and humidity. Refer to the system's Operation Guide for more information on run times and the change intervals of consumables.

Note on handling the toner containers: Do not open the toner containers. When replacing them, please follow the instructions in the operating manual. Do not inhale any leaking toner as a result of improper handling, but wipe it off with a damp cloth. Avoid skin contact. If toner gets onto the skin, wash affected areas with plenty of cold water and soap. **Keep toner (old or new) out of the reach of children!**

6 Warranty and spare parts

The guarantee for the devices corresponds to the legal regulations, as far as these are binding. All Ricoh distributors and subsidiaries offer all-in service contracts that go beyond the legal warranty. Please contact your local Ricoh office or distributor. Consumables and essential spare parts are available at least 5 years after the last unit in this series was sold.

7 Cleaning and Maintenance

Cleaning, maintenance and disposal activities may only be carried out by qualified personnel. Further information on cleaning and maintenance of the system can be found in the chapter "Maintenance and Specification" of the operating instructions.

8 Power Consumption	Determined according to DE U	Determined according to DE UZ 219 and ENERGY STAR® in delivery condition		
Operating Mode	Default Delay Time	Default Delay Time Return Time ²⁾ (s)		
Maximum Power Consumption			1200	
Continuous Operation 30 ppm (15 min. printing time) monochrom		427		
Ready	0	0	44.1	
Sleep Mode	1 or press energy saving button	9	0.9	
Off Mode U	Switch	Switch < 0.3		
TEC (Typical Electricity Consumption) based on ENERGY STAR® 3.0 test method			0.37 kWh/week	

¹⁾ Default Delay Time: The time that elapses after the end of the printing process until the device automatically switches to an idle state.
2) Return Time: The time it takes for the device to return from an energy-saving state to a print-ready state.

This product is designed to save energy costs. The system automatically reduces energy consumption when not used for a period of time (1 minute). This mode is called Sleep Mode. From these states, the machine returns to standby printing in a short time (the return time listed above) when it receives a print or copy job. This allows you to save energy without limiting your productivity. With its return time, the system meets the high requirements of the Blue Angel, which attaches particular importance to user-friendliness in this respect.

The activation times for the sleep mode can be changed by the user in the range 1-60 minutes.

System: IM C300

Ausgabe: 01 January 2025

Seite 3 von 4



However, if the activation times are increased, this leads to higher energy consumption and thus to higher electricity costs. It is therefore recommended not to change the preset activation times.

When the main switch is actuated, there is still a low power consumption of max. 0.2 watts. Complete disconnection from the mains can be achieved by pulling the mains plug. Please observe the instructions in the operating instructions in order to prevent damage to the system and possible loss of data.

The device is designed so that it can be switched off at least twice a day.

Note on TEC (Typical Electricity Consumption). The aim of the TEC method is to determine the energy efficiency of hardcopy devices (copiers, printers, multifunction systems) and to make them comparable. The method determines the energy consumption of a product over a fixed period of time under normal operating conditions.

The following usage cycle is assumed for the present system:

Per working day 30 print jobs with 15 pages, simplex at monochrome printing, (450 pages/day).

Hence, the energy consumption for a week in standard usage cycle according to ENER-GY STAR® (7-day-week with 5 working days of 8 hours) is 0.34 kWh per week.

9 **Noise Emissions** According to DE-UZ 219 clause 3.5 printing mode 9.1 Declared Sound Power Level (LwAc in dB(A))BW 65.1 Declared Sound Power Level (LwAc in dB(A))Co 65.2 According to ISO 7779 in combination with ISO 9296 9.2 Standby Operation Monochr. Operation Col. 30.7 62.2 Sound Power Level (LwA in dB(A)) 628 Declared Sound Power Level (Lwas in B(A)) 3.4 6.5 6.6 Sound pressure level operator position (LpA in dB(A)) 20.5 53.9 55.7 Sound pressure level bystander position (LpA in dB(A)) 21.3 52.4 52.8 Chemical emissions determined according to ISO/IEC 28360 with DE-UZ 219

		Monochrome		Full Colour	
		Measured Value	Reference value DE-UZ 219 (Blue Angel Mark)	Measured Value	Reference value DE-UZ 219 (Blue Angel Mark)
Pre-Operating Phase	TVOC [mg/h]	0.199	2	0.199	2
	TVOC [mg/h]	1.7	10	1.7	18
Printing Phase	Benzene [mg/h]	< 0.02	< 0,05	< 0.02	< 0,05
(Sum of	Styrene [mg/h]	0.08	1,0	0.08	1,8
Printing and Pre-operating	Non identified VOC [mg/h]	< 0.05	0,9	< 0.05	0,9
phase)	Ozone [mg/h]	0.43	1,5	0.43	3,0
	Dust [mg/h]	0.4	4,0	0.4	4,0
Printing Phase	PER10 PW [Partikel/10min]	0.08* 10 ¹¹	3,5 * 10 ¹¹	0.08 * 10 ¹¹	3,5 * 10 ¹¹

_OD = Limit of	detection.	I 00 =	I imit of	qualification

Blue Angel recommendation: New electronic devices generally emit volatile substances into the room air. For this reason, sufficient air exchange in the installation rooms and, if necessary, at the workplace should be ensured, especially in the first few days after the unit has been installed.

Γhe system is equipped with an ozone filter:	Yes: 🛛	Not applicable:]
The system is equipped with dust filters:.	Yes: 🛛	Not applicable:]
Further information on the filter change cycle can be	e found in the	operating instruction	าร

System: IM C300 Ausgabe: 01 January 2025 Seite 4 von 4



11 Recycling	
Empty toner cartridges	☐ Collection via Ricoh Resource Smart Return Program
Full toner cartridges	Filled waste toner containers should not be disposed of with household and commercial waste. They can be handed in at any RICOH branch and at any RICOH contractual partner.
Waste Toner	☐ Not applicable.☑ Please dispose according to local legislation
Batteries	☐ Collection according to local legislation.☐ No battery used.
Photo Conductor units and spare parts	⊠ Return via Ricoh Resource Smart Return Program
Devices	Used equipment is taken back and recycled in an environmentally friendly manner or - if this is no longer possible - recycled. Information about collection points for used RICOH products in your country can be obtained from your dealers or via the RICOH website: Contact: https://www.ricoh-europe.com
Information on Ricoh's pan-Eur	opean consumables collection system can be found on the following website: https://www.ricoh-return.com
12 Other	
	et is based on the current state of our knowledge. They do not represent any assurance of escribed within the meaning of the statutory warranty regulations.

Latest Change:

01 January 2025: Update Power Consumptiion Dat

This edition replaces all previous versions.