

# Blue Angel Environmental Information and Data Sheet Model: IM C300F

EDP: 418572

Issued: 01 January 2025

1 General Specification					
Primary functions of the base unit					
Model: IM C300F		⊠ Сору	☑ Print	☐ Fax	⊠ Scan
Tachnology		☐ Monochrom	е	⊠ Colour	
Technology	⊠ Electrophotographic		☐ Inkjet Technology		
Print Speed Simplex, DIN-A4 pages/min, according to ISO/IEC 24734		Monochrome: 30 Colour: 30			
Copying Speed Simplex, DIN-A4 pages/min, according to ISO/IEC 24735		Monochrome: 30		Colour: 30	
The system is designed for use in the professional/commercial sector.					
2 Technical Safety (Declaration of Conformity					
The system complies with the following EU regulations as far as they are applicable and bears the CE mark					
<ul> <li>Radio Equipment Directive 2014/53/EU</li> <li>RoHS Directive 2011/65/EU</li> <li>ErP Directive 2009/125/EC</li> </ul>					
3 Environmental Labels					
www.blauer-engel.de/uz219  • geringer Energieverbrauch • emissions- und lärmarm • langlebig  The TEC value of the product based on the ENERGY STAR® Version 3.0 Test Method, and tested by the manufacturer, satisfies the program requirements.  The requirements of the Blue Angel DE-UZ 219 eco-label were tested and met with the toner supplied and recommended by Ricoh. Further information on the Blue Angel can be found at: <a href="https://www.blauer-engel.de/en">https://www.blauer-engel.de/en</a>					
4 Use and labelling of materia					
Paper	The device is suitable for processing recycled paper that complies with EN 12281:2002. We recommend using the machine in duplex mode (double-sided copy/print). The model is equipped with a duplex and N-up function:  Standard  Optional				
Toner/ Ink		☐ Ink	•		
Ames-Test	Negative (refer to Safety Data Sheet)				
Photo Conductor Unit	Organic Photo Conductor (OPC)				
Batteries	Mangandioxide Lithium free of lead, cadmium and mercury				
Flame Retardents	<ul><li>25 g, especially</li><li>Polybromina</li><li>Polybromina</li></ul>		(PBB), er (PBDE) and	ing parts and other p	plastic parts over

System: IM C300F Ausgabe: 01 January 2025

Seite 2 von 4



Marking of Plastic Parts	All plastic parts >25g are marked in accordance with ISO 11469:2000 and ISO 1043.				
Proportion by weight of	□ 0 – 1 %		☐ 10 – 15 %		
recycled plastic relative to total	□ 1 – 5 %		☐ 15 – 20 %		
plastic (Post-consumer)	⊠ 5 – 10 %		☐ 20 – 25 %		
Legal requirements for recycling (WEEE)	The device fully complies with WEEE requirements.				
5 Yield of consumables					
Consumable	Description	EDP	Yield (A4)	Test Procedure	
Consumable	Description  Print Cartridge Black IM C300	<b>EDP</b> 842382	<b>Yield (A4)</b> 19,300	Test Procedure	
	•		` ,		
Consumable  Toner Cartridges	Print Cartridge Black IM C300	842382	19,300	Test Procedure	
	Print Cartridge Black IM C300 Print Cartridge Yellow IM C300	842382 842383	19,300 10,300		

**Note on the ranges given here:** The actual yield depends on the image size and brightness, the number of pages to be printed at one time, the type and size of paper used, the contents of the printed images, and environmental conditions such as temperature and humidity. Refer to the system's Operation Guide for more information on run times and the change intervals of consumables.

**Note on handling the toner containers:** Do not open the toner containers. When replacing them, please follow the instructions in the operating manual. Do not inhale any leaking toner as a result of improper handling, but wipe it off with a damp cloth. Avoid skin contact. If toner gets onto the skin, wash affected areas with plenty of cold water and soap. **Keep toner (old or new) out of the reach of children!** 

#### 6 Warranty and spare parts

The guarantee for the devices corresponds to the legal regulations, as far as these are binding. All Ricoh distributors and subsidiaries offer all-in service contracts that go beyond the legal warranty. Please contact your local Ricoh office or distributor. Consumables and essential spare parts are available at least 5 years after the last unit in this series was sold.

## 7 Cleaning and Maintenance

Cleaning, maintenance and disposal activities may only be carried out by qualified personnel. Further information on cleaning and maintenance of the system can be found in the chapter "Maintenance and Specification" of the operating instructions.

8 Power Consumption	Determined according to DE U	Determined according to DE UZ 219 and ENERGY STAR® in delivery condition				
Operating Mode	Default Delay Time	Return Time <sup>2)</sup> (s)	Power Consumption (Watt)			
Maximum Power Consumption			1200			
Continuous Operation 30 ppm (15 min. printing time) monochrom			427			
Ready	0	0	44.1			
Sleep Mode	1 or press energy saving button	1 37 3 1 4				
Off Mode	Switch	Switch				
TEC (Typical Electricity Consumption) based on ENERGY STAR® 3.0 test method			0.37 kWh/week			

<sup>1)</sup> Default Delay Time: The time that elapses after the end of the printing process until the device automatically switches to an idle state.
2) Return Time: The time it takes for the device to return from an energy-saving state to a print-ready state.

This product is designed to save energy costs. The system automatically reduces energy consumption when not used for a period of time (1 minute). This mode is called Sleep Mode. From these states, the machine returns to standby printing in a short time (the return time listed above) when it receives a print or copy job. This allows you to save energy without limiting your productivity. With its return time, the system meets the high requirements of the Blue Angel, which attaches particular importance to user-friendliness in this respect.

The activation times for the sleep mode can be changed by the user in the range 1-60 minutes.

System: IM C300F Ausgabe: 01 January 2025

**Noise Emissions** 

Seite 3 von 4

9



However, if the activation times are increased, this leads to higher energy consumption and thus to higher electricity costs. It is therefore recommended not to change the preset activation times.

When the main switch is actuated, there is still a low power consumption of max. 0.2 watts. Complete disconnection from the mains can be achieved by pulling the mains plug. Please observe the instructions in the operating instructions in order to prevent damage to the system and possible loss of data.

The device is designed so that it can be switched off at least twice a day.

**Note on TEC (Typical Electricity Consumption).** The aim of the TEC method is to determine the energy efficiency of hardcopy devices (copiers, printers, multifunction systems) and to make them comparable. The method determines the energy consumption of a product over a fixed period of time under normal operating conditions.

### The following usage cycle is assumed for the present system:

Per working day 30 print jobs with 15 pages, simplex at monochrome printing, (450 pages/day).

Hence, the energy consumption for a week in standard usage cycle according to ENER-GY STAR® (7-day-week with 5 working days of 8 hours) is 0.34 kWh per week.

#### According to DE-UZ 219 clause 3.5 printing mode 9.1 Declared Sound Power Level (LwAc in dB(A) )BW 65.1 Declared Sound Power Level (LwAc in dB(A) )Co 65.2 According to ISO 7779 in combination with ISO 9296 9.2 Standby Operation Monochr. Operation Col. 30.7 62.2 Sound Power Level (LwA in dB(A)) 628 Declared Sound Power Level (Lwas in B(A)) 6.6 3.4 6.5 Sound pressure level operator position (LpA in dB(A)) 20.5 53.9 55.7 Sound pressure level bystander position (LpA in dB(A)) 52.4 21.3 52.8 Chemical emissions determined according to ISO/IEC 28360 with DE-UZ 219 Monochrome **Full Colour** Reference value Reference value Measured Measured **DE-UZ 219 DE-UZ 219** Value Value (Blue Angel Mark) (Blue Angel Mark) **Pre-Operating** TVOC [mg/h] 0.199 2 0.199 2 **Phase** 1.7 1.7 TVOC [mg/h] 10 18 Benzene [mg/h] < 0.02 < 0,05 < 0.02 < 0,05 **Printing Phase** (Sum of Styrene [mg/h] 80.0 80.0 1,0 1,8 **Printing and** Non identified VOC < 0.05 0.9 < 0.05 0.9 **Pre-operating** [mg/h] phase) Ozone [mg/h] 0.43 1,5 0.43 3.0 Dust [mg/h] 0.4 4.0 0.4 4.0 PER10 PW 0.08\* 1011 $3.5 * 10^{11}$ $0.08 * 10^{11}$ $3.5 * 10^{11}$ **Printing Phase** [Partikel/10min] LOD = Limit of detection, LOQ = Limit of qualification Blue Angel recommendation: New electronic devices generally emit volatile substances into the room air. For this reason, sufficient air exchange in the installation rooms and, if necessary, at the workplace should be ensured, especially in the first few days after the unit has been installed. The system is equipped with an ozone filter: Yes: Not applicable: The system is equipped with dust filters:. Yes: Not applicable: Further information on the filter change cycle can be found in the operating instructions...

System: IM C300F Ausgabe: 01 January 2025 Seite 4 von 4



11 Recycling		
Empty toner cartridges	☐ Collection via Ricoh Resource Smart Return Program	
Full toner cartridges	Filled waste toner containers should not be disposed of with household and commercial waste. They can be handed in at any RICOH branch and at any RICOH contractual partner.	
Waste Toner	<ul><li>☐ Not applicable.</li><li>☑ Please dispose according to local legislation</li></ul>	
Batteries	<ul><li>☐ Collection according to local legislation.</li><li>☐ No battery used.</li></ul>	
Photo Conductor units and spare parts	⊠ Return via Ricoh Resource Smart Return Program	
Devices	Used equipment is taken back and recycled in an environmentally friendly manner or - if this is no longer possible - recycled.  Information about collection points for used RICOH products in your country can be obtained from your dealers or via the RICOH website:  Contact: <a href="https://www.ricoh-europe.com">https://www.ricoh-europe.com</a>	
Information on Ricoh's pan-European consumables collection system can be found on the following website: <a href="https://www.ricoh-return.com">https://www.ricoh-return.com</a>		
12 Other		
	et is based on the current state of our knowledge. They do not represent any assurance of	

# Latest Change:

01 January 2025: Update Power Consumptiion Data

This edition replaces all previous versions.