

Blue Angel Environmental Information and Data Sheet Model: IM C400SRF

Issued: 01 January 2025

EDP: 418575

1 General Specification Primary functions of the base unit					
Primary functions of the base unit					
Model : IM C400SRF	🛛 Сору	🛛 Print	🗌 Fax	🛛 Scan	
Technology			🖂 Colour		
	Electropho	otographic	🗌 Inkjet Tech	Inkjet Technology	
Print Speed Simplex, DIN-A4 pages/min, according to ISO/IEC 24734	Monochrome	Monochrome: 43		Colour: 40	
Copying Speed Simplex, DIN-A4 pages/m according to ISO/IEC 24735	in, Monochrome:	Monochrome: 43		Colour: 40	
The system is designed for use in the pro	The system is designed for use in the professional/commercial sector.				
2 Technical Safety (Declaration of Con	nformity				
The system complies with the following B	EU regulations as far	as they are app	licable and bears	the CE mark	
 Radio Equipment Directive 2014/53/EU RoHS Directive 2011/65/EU ErP Directive 2009/125/EC 					
3 Environmental Labels					
www.blauer-engel.de/uz219 . geringer Energieverbrauch . emissions- und lärmarm . langlebig The TEC value of the product based on the ENERGY STAR® Version 3.0 Test Method, and tested by the manufacturer, satisfies the program requirements. The requirements of the Blue Angel DE-UZ 219 eco-label were tested and met with the toner supplied and recommended					
by Ricoh. Further information on the Blue Angel can be found at: <u>https://www.blauer-engel.de/en</u> 4 Use and labelling of materials					
Paper The device is suitable for processing recycled paper that complies with EN 12281:2002 We recommend using the machine in duplex mode (double-sided copy/print). The model is equipped with a duplex and N-up function: Standard Optional					
Toner/ Ink	Toner Ink				
Ames-Test Negative	Negative (refer to Safety Data Sheet)				
Photo Conductor Unit Organic	Organic Photo Conductor (OPC)				
Batteries Mangan	Mangandioxide Lithium free of lead, cadmium and mercury				
Flame Retardents 25 g, es • Poly • Poly	Polybrominated Biphenylether (PBDE) and				



Marking of Plastic Parts	All plastic parts >25g are marked in accordance with ISO 11469:2000 and ISO 1043.				
Proportion by weight of recycled plastic relative to total	□ 0 − 1 % □ 10 − 15 %				
plastic	□ 1 – 5 % ⊠ 5 – 10 %		5 – 20 % 0 – 25 %		
(Post-consumer) Legal requirements for	The device fully complies with WEEE requirements.				
recycling (WEEE)					
5 Yield of consumables	Γ				
Consumable	Description	Description EDP Yield		Test Procedure	
	Print Cartridge Black IM C400	842374	19,800	ISO/IEC 19798	
Toner Cartridges	Print Cartridge Yellow IM C400	842375	13,700		
roher oarthuges	Print Cartridge Magenta IM C400	842376	13,700	100/120 13/ 30	
	Print Cartridge Cyan IM C400	842377	13,700		
Starter Cartridge	No starter cartridge included				
Note on the ranges given here: The actual yield depends on the image size and brightness, the number of pages to be printed at one time, the type and size of paper used, the contents of the printed images, and environmental conditions such as temperature and humidity. Refer to the system's Operation Guide for more information on run times and the change intervals of consumables.					
Note on handling the toner containers: Do not open the toner containers. When replacing them, please follow the instructions in the operating manual. Do not inhale any leaking toner as a result of improper handling, but wipe it off with a damp cloth. Avoid skin contact. If toner gets onto the skin, wash affected areas with plenty of cold water and soap. Keep toner (old or new) out of the reach of children!					
6 Warranty and spare parts					
The guarantee for the devices corresponds to the legal regulations, as far as these are binding. All Ricoh distributors and subsidiaries offer all-in service contracts that go beyond the legal warranty. Please contact your local Ricoh office or distributor. Consumables and essential spare parts are available at least 5 years after the last unit in this series was sold.					
7 Cleaning and Maintenance					
Cleaning, maintenance and disposal activities may only be carried out by qualified personnel. Further information on cleaning and maintenance of the system can be found in the chapter "Maintenance and Specification" of the operating instructions.					
8 Power Consumption	Determined according to DE UZ	219 and ENEF	RGY STAR® in c	lelivery condition	
Operating Mode	Default Delay Time	Return Time	²⁾ (s) Powe	r Consumption (Watt)	
Maximum Power Consumption			1350		
Continuous Operation 43 ppm (15 min. printing time) monochrom 621			621		
Ready	0	0		52.4	
Sleep Mode	1 or press energy saving button	4		< 0.9	
Off Mode	Switch			< 0.3	
TEC (Typical Electricity Consumption) based on ENERGY STAR® 3.0 test method 0.52 kWh/week					
 Default Delay Time: The time that elapses after the end of the printing process until the device automatically switches to an idle state. Return Time: The time it takes for the device to return from an energy-saving state to a print-ready state. 					
This product is designed to save energy costs. The system automatically reduces energy consumption when not used for a period of time (1 minute). This mode is called Sleep Mode. From these states, the machine returns to standby printing in a short time (the return time listed above) when it receives a print or copy job. This allows you to save energy without limiting your productivity. With its return time, the system meets the high requirements of the Blue Angel, which attaches particular					

importance to user-friendliness in this respect. The activation times for the sleep mode can be changed by the user in the range 1-60 minutes.



However, if the activation times are increased, this leads to higher energy consumption and thus to higher electricity costs. It is therefore recommended not to change the preset activation times.

When the main switch is actuated, there is still a low power consumption of max. 0.2 watts. Complete disconnection from the mains can be achieved by pulling the mains plug. Please observe the instructions in the operating instructions in order to prevent damage to the system and possible loss of data.

The device is designed so that it can be switched off at least twice a day.

Note on TEC (Typical Electricity Consumption). The aim of the TEC method is to determine the energy efficiency of hardcopy devices (copiers, printers, multifunction systems) and to make them comparable. The method determines the energy consumption of a product over a fixed period of time under normal operating conditions.

The following usage cycle is assumed for the present system:

Per working day 32 print jobs with 28 pages, simplex at monochrome printing, (896 pages/day).

Hence, the energy consumption for a week in standard usage cycle according to ENER-GY STAR® (7-day-week with 5 working days of 8 hours) is 0.50 kWh per week.

9 Noise Emissions			
9.1 According to DE-UZ 219 clause 3.5 printing mode			
Declared Sound Power Level (L _{WAc} in dB(A))BW 70.3			
Declared Sound Power Level (LwAc in dB(A))Co	rer Level (LwAc in dB(A))Co 70.6		
9.2 According to ISO 7779 in combination with ISO 9296			
	Standby	Operation Monochr.	Operation Col.
Sound Power Level (L _{WA} in dB(A))	30.7	68.5	68.6
Declared Sound Power Level (L _{was} in B(A))	3.4	7.2	7.2

Sound pressure level operator position (L_{pA} in dB(A)) 20.9 61.8 61.8 Sound pressure level bystander position (L_{pA} in dB(A)) 19.9 57.0 56.7

Chemical emissions determined according to ISO/IEC 28360 with DE-UZ 219 10

		Monochrome		Full Colour	
		Measured Value	Reference value DE-UZ 219 (Blue Angel Mark)	Measured Value	Reference value DE-UZ 219 (Blue Angel Mark)
Pre-Operating Phase	TVOC [mg/h]	0.064	2	0.1	2
Printing Phase (Sum of	TVOC [mg/h]	1.3	10	2.2	18
	Benzene [mg/h]	0.011	< 0,05	0.011	< 0,05
	Styrene [mg/h]	0.037	1,0	0.069	1,8
Printing and Pre-operating	Non identified VOC [mg/h]	0.062	0,9	0.052	0,9
phase)	Ozone [mg/h]	< 0.2 (LOD)	1,5	< 0.2 (LOD)	3,0
	Dust [mg/h]	< 0.18 (LOD)	4,0	< 0.18 (LOD)	4,0
Printing Phase	PER10 PW [Partikel/10min]	1.3* 10 ¹¹	2,5 * 10 ¹¹	1.3 * 10 ¹¹	2,5 * 10 ¹¹

LOD = Limit of detection, LOQ = Limit of gualification

Blue Angel recommendation: New electronic devices generally emit volatile substances into the room air. For this reason, sufficient air exchange in the installation rooms and, if necessary, at the workplace should be ensured, especially in the first few days after the unit has been installed.

Yes:

The system is equipped with an ozone filter:

Not applicable: Not applicable:

The system is equipped with dust filters:. Yes: 🗍 Further information on the filter change cycle can be found in the operating instructions.



11 Recycling		
Empty toner cartridges	Collection via Ricoh Resource Smart Return Program	
Full toner cartridges	Filled waste toner containers should not be disposed of with household and commercial waste. They can be handed in at any RICOH branch and at any RICOH contractual partner.	
Waste Toner	 ☐ Not applicable. ☑ Please dispose according to local legislation 	
Batteries	 ☐ Collection according to local legislation. ☐ No battery used. 	
Photo Conductor units and spare parts	Return via Ricoh Resource Smart Return Program	
Devices	Used equipment is taken back and recycled in an environmentally friendly manner or - if this is no longer possible - recycled. Information about collection points for used RICOH products in your country can be obtained from your dealers or via the RICOH website: Contact: <u>https://www.ricoh-europe.com</u>	
Information on Ricoh's pan-European consumables collection system can be found on the following website: https://www.ricoh-return.com		
12 Other		
All information in this data sheet is based on the current state of our knowledge. They do not represent any assurance of the properties of the product described within the meaning of the statutory warranty regulations.		

Latest Change:

01 January 2025: Update Power Consumptiion Data

This edition replaces all previous versions.