


Blue Angel Environmental Information and Data Sheet


Model: SP C360SFNw/ SP C361SFNw

EDP: 408171/ 408175

Issued: 18th August 2021 applicable from SN C791R400001/ C801R400001

1 General Specification	
Primary functions of the base unit	
Model : SP C360SFNw/ SP C361SFNw	<input checked="" type="checkbox"/> Copy <input checked="" type="checkbox"/> Print <input checked="" type="checkbox"/> Fax <input checked="" type="checkbox"/> Scan
Technology	<input type="checkbox"/> Monochrome <input checked="" type="checkbox"/> Colour
	<input checked="" type="checkbox"/> Electrophotographic <input type="checkbox"/> Inkjet Technology
Print Speed Simplex, DIN-A4 pages/min, according to ISO/IEC 24734	Monochrome: 30 Colour: 30
Copying Speed Simplex, DIN-A4 pages/min, nach ISO/IEC 24735	Monochrome: NA Colour: NA
The system is designed for use in the professional/commercial sector.	
2 Technical Safety (Declaration of Conformity)	
The system complies with the following EU regulations as far as they are applicable and bears the CE mark	
<ul style="list-style-type: none"> • Radio Equipment Directive 2014/53/EU • RoHS Directive 2011/65/EU • ErP Directive 2009/125/EC 	
3 Environmental Labels	
<div style="border: 1px solid blue; padding: 10px;">  <p>www.blauer-engel.de/uz219</p> <ul style="list-style-type: none"> • low energy consumption • low emissions and noise • durable </div>	
<p>The TEC value of the product based on the ENERGY STAR® Version 3.0 Test Method, and tested by the manufacturer, satisfies the program requirements.</p> <p>The requirements of the Blue Angel DE-UZ 219 eco-label were tested and met with the toner supplied and recommended by Ricoh. Further information on the Blue Angel can be found at: https://www.blauer-engel.de/en</p>	
4 Use and labelling of materials	
Paper	The device is suitable for processing recycled paper that complies with EN 12281:2002. We recommend using the machine in duplex mode (double-sided copy/print). The model is equipped with a duplex and N-up function: <input checked="" type="checkbox"/> Standard <input type="checkbox"/> Optional
Toner/ Ink	<input checked="" type="checkbox"/> Toner <input type="checkbox"/> Ink
Ames-Test	Negative (refer to Safety Data Sheet)
Photo Conductor Unit	Organic Photo Conductor (OPC)
Batteries	Lithium Ion Battery free of lead, cadmium and mercury
Flame Retardants	No halogenated flame retardants are used in housing parts and other plastic parts over 25 g, especially not: <ul style="list-style-type: none"> • Polybrominated Biphenyles (PBB), • Polybrominated Biphenylether (PBDE) and • Tetrabrombisphenol A (TBBPA).

Marking of Plastic Parts	All plastic parts >25g are marked in accordance with ISO 11469:2000 and ISO 1043.			
Proportion by weight of recycled plastic relative to total plastic (Post-consumer)	<input type="checkbox"/> 0 – 1 % <input type="checkbox"/> 1 – 5 % <input checked="" type="checkbox"/> 5 – 10 %	<input type="checkbox"/> 10 – 15 % <input type="checkbox"/> 15 – 20 % <input type="checkbox"/> 20 – 25 %		
Legal requirements for recycling (WEEE)	The device fully complies with WEEE requirements.			
5 Yield of consumables				
Consumable	Description	EDP	Yield (A4)	Test Procedure
Toner Cartridges	Print Cartridge Black SP C360X*/HE/E	408250*/ 408184/ 408188	10,000*/ 9,000/ 2,500	ISO/IEC 19798
	Print Cartridge Cyan SP C360X*/HE/E	408251*/ 408185/ 408189	9,000*/ 5,000/ 1,500	
	Print Cartridge Magenta SP C360X*/HE/E	408252*/ 408186/ 408190	9,000*/ 5,000/ 1,500	
	Print Cartridge Yellow SP C360X*/HE/E	408253*/ 408187/ 408191	9,000*/ 5,000/ 1,500	
*only applicable for SP C361SFNw				
Starter Cartridge	The system is supplied with a starter cartridge. yield. 2,500 A4-pages (black) and 1,500 A4-pages (Colours)			
Other consumable	Black Drum Unit SP C352	407404	15,000	A4 template 5% coverage; 3 pages/Job
	Color Drum Unit SP C352	407405	12,000	
	Fusing Unit SP C352	407407	150,000	A4 template 5% coverage; 3 pages/Job; 50% B&W/50% FC
	Transfer Unit SP C352	407408	100,000	
	Waste Toner Bottle SP C352	408110	13,000	
<p>Note on the ranges given here: The actual yield depends on the image size and brightness, the number of pages to be printed at one time, the type and size of paper used, the contents of the printed images, and environmental conditions such as temperature and humidity. Refer to the system's Operation Guide for more information on run times and the change intervals of consumables.</p> <p>Print cartridges (consumables) are excluded from the warranty. In case of problems, please contact the dealer from whom you purchased it.</p> <p>When using the device for the first time, use the print cartridges supplied with the device.</p> <p>This machine cleans itself periodically to maintain quality and uses toner during this process. For more information on runtimes and the respective change cycle of the consumables, refer to the operating instructions for the system.</p>				
<p>Note on handling the toner containers: Do not open the toner containers. When replacing them, please follow the instructions in the operating manual. Do not inhale any leaking toner as a result of improper handling, but wipe it off with a damp cloth. Avoid skin contact. If toner gets onto the skin, wash affected areas with plenty of cold water and soap.</p> <p>Keep toner (old or new) out of the reach of children!</p>				
6 Warranty and spare parts				
<p>The warranty for the devices complies with the legal regulations, insofar as these are binding. All Ricoh distributors and subsidiaries offer all-in service contracts that extend beyond the statutory warranty. Please contact your local Ricoh office or the nearest distributor from whom you purchased the equipment. Consumables and vital spare parts are available for at least 5 years after the last device of this series has been sold.</p> <p>For more information, please contact Ricoh eService: https://eservice.ricoh-europe.com</p>				

7 Cleaning and Maintenance			
Cleaning, maintenance and disposal activities may only be carried out by qualified personnel. Further information on cleaning and maintenance of the system can be found in the chapter "Maintenance and Specification" of the operating instructions.			
8 Power Consumption		Determined according to DE-UZ 219 and ENERGY STAR® in delivery condition	
Operating Mode	Default Delay Time (min)	Return Time ²⁾ (s)	Power Consumption (Watt)
Maximum Power Consumption			1200
Continuous Operation 30 ppm (15 min. printing time) monochrom			469
Ready	0	0	33.3
Sleep Mode	1 or press energy saving button	8	< 1.4
Off Mode 	Main Switch		0.2
TEC (Typical Electricity Consumption) according to ENERGY STAR®			0.5 kWh/Woche
1) <i>Default Delay Time: The time that elapses after the end of the printing process until the device automatically switches to an idle state.</i> 2) <i>Return Time: The time it takes for the device to return from an energy-saving state to a print-ready state.</i>			
<p>This product is designed to save energy costs. The system automatically reduces energy consumption when not used for a period of time (30 seconds). This mode is called Sleep Mode. From these state, the machine returns to standby printing in a short time (the return time listed above) when it receives a print or copy job. This allows you to save energy without limiting your productivity. With its return time, the system meets the high requirements of the Blue Angel, which attaches particular importance to user-friendliness in this respect.</p> <p>The activation times for the sleep mode can be changed by the user in the range 1-60 minutes. However, if the activation times are increased, this leads to higher energy consumption and thus to higher electricity costs. It is therefore recommended not to change the preset activation times.</p> <p>When the main switch is actuated, there is still a low power consumption of max. 0.2 watts. Complete disconnection from the mains can be achieved by pulling the mains plug. Please observe the instructions in the operating instructions in order to prevent damage to the system and possible loss of data.</p> <p>The device is designed so that it can be switched off at least twice a day.</p> <p>Note on TEC (Typical Electricity Consumption). The aim of the TEC method is to determine the energy efficiency of hardcopy devices (copiers, printers, multifunction systems) and to make them comparable. The method determines the energy consumption of a product over a fixed period of time under normal operating conditions.</p> <p>The following usage cycle is assumed for the present system: Per working day 30 print jobs with 15 pages, simplex at monochrome printing, (450 pages/day). Hence, the energy consumption for a week in standard usage cycle according to ENER-GY STAR® version 2.0 (7-day-week with 5 working days of 8 hours) is 0.5 kWh per week.</p>			
9 Noise Emissions			
9.1 According to DE-UZ 219 clause 3.5 printing mode			
Declared Sound Power Level (L_{WAd} in dB(A)) BW			67.5
Declared Sound Power Level (L_{WAd} in dB(A)) Co			67.4
9.2 According to ISO 7779 in combination with ISO 9296			
	Standby	Operation Monochr.	Operation Col.
Sound Power Level (L_{WA} in dB(A))	29.8	64.1	64.3
Declared Sound Power Level (L_{WAd} in B(A))	3.3	6.7	6.7
Sound pressure level operator position (L_{pA} in dB(A))	20.0	57.4	57.3
Sound pressure level bystander position (L_{pA} in dB(A))	19.8	52.7	53.0

10 Chemical emissions determined according to ISO/IEC 28360 with DE-UZ 219					
		Monochrome		Full Colour	
		Measured Value	Reference value DE-UZ 219 (Blue Angel Mark)	Measured Value	Reference value DE-UZ 219 (Blue Angel Mark)
Pre-Operating Phase	TVOC [mg/h]	0.028	1	0.029	1
Printing Phase (Sumo f Printing and Pre-operating phase)	TVOC [mg/h]	2.4	10	4.4	18
	Benzene [mg/h]	< 0.007 (LOQ)	< 0,05	0.012	< 0,05
	Styrene [mg/h]	< 0.003 (LOD)	1,0	0.027	1,8
	Non identified VOC [mg/h]	0.067	0,9	0.092	0,9
	Ozone [mg/h]	< 0.2 (LOD)	1,5	< 0.2 LOD	3,0
Printing Phase	Dust [mg/h]	< 0.6 (LOQ)	4,0	< 0.18 (LOD)	4,0
Printing Phase	PER10 PW [Partikel/10min]	--> * 10 ¹¹	3,5 * 10 ¹¹	2.3 * 10 ¹¹	3,5 * 10 ¹¹
LOD = Limit of detection, LOQ = Limit of qualification Blue Angel recommendation: New electronic devices generally emit volatile substances into the room air. For this reason, sufficient air exchange in the installation rooms and, if necessary, at the workplace should be ensured, especially in the first few days after the unit has been installed. The system is equipped with an ozone filter: Yes: <input type="checkbox"/> Not applicable: <input checked="" type="checkbox"/> The system is equipped with dust filters: Yes: <input type="checkbox"/> Not applicable: <input checked="" type="checkbox"/> Further information on the filter change cycle can be found in the operating instructions..					
11 Recycling					
Empty toner cartridges	<input checked="" type="checkbox"/> Collection via Ricoh Resource Smart Return Program				
Full toner cartridges	Filled waste toner containers should not be disposed of with household and commercial waste. They can be handed in at any RICOH branch and at any RICOH contractual partner.				
Waste Toner	<input type="checkbox"/> Not applicable. <input checked="" type="checkbox"/> Please dispose according to local legislation				
Batteries	<input checked="" type="checkbox"/> Collection according to local legislation. <input type="checkbox"/> No battery used.				
Photo Conductor units and spare parts	<input type="checkbox"/> Return via Ricoh Resource Smart Return Program				
Devices	Used equipment is taken back and recycled in an environmentally friendly manner or - if this is no longer possible - recycled. Information about collection points for used RICOH products in your country can be obtained from your dealers or via the RICOH website: Contact: https://www.ricoh-europe.com				
Information on Ricoh's pan-European consumables collection system can be found on the following website: https://www.ricoh-return.com					
12 Other					
All information in this data sheet is based on the current state of our knowledge. They do not represent any assurance of the properties of the product described within the meaning of the statutory warranty regulations.					

new.